



# Titan Air Lifting Bar Instructions

The Titan Air Lifting bar is to be used to help lift Titan Air's Personnel lifts into place.

One lifting bar is bolted to a Titan Air Personnel Lift.

After the lift is put in place, the lifting bar is to be removed and used to lift any other Titan Air lifts.

This bar is also needed when a lift is to be taken down.

**Lifting Bar**



**Titan Air Incorporated**

PO Box 717 Osseo, WI 54748 Phone: 715-597-2050 Fax: 715-597-3620 sales@titan-air.com www.titan-air.com